

# ACCU-VENT

## Automatic Degassing Valves

### 2019 Canadian Price List

#### Standard Features

- CPVC (Corzan) corrosion-resistant materials of construction on standard models
- Specially designed float material that automatically vents built-up gases on system start up and under working pressure
- Can be used on feed side or discharge side of pump (or both)
- Available in Stainless Steel for specific chemical, temperature, and pressure applications
- Also available in compact style, with 1/4" connection

Model	Material	Bottom Connection	Top Connection	Max. Temp.	Max. Pressure	Price
<b>AV-25-CPVC</b>	CPVC	1/4" NPT or BSP Thread	1/4" Thread	180 F (82 C)	150 PSIG	\$130.00
<b>AV-50-CPVC</b>	CPVC	1/2" NPT or BSP Thread	1/2" Thread	180 F (82 C)	150 PSIG	\$205.00
<b>AV-50-CPVC-S</b>	CPVC	Socketweld	1/2" Thread	180 F (82 C)	150 PSIG	\$205.00
<b>AV-75-CPVC</b>	CPVC	3/4" NPT or BSP Thread	1/2" Thread	180 F (82 C)	150 PSIG	\$205.00
<b>AV-75-CPVC-S</b>	CPVC	Socketweld	1/2" Thread	180 F (82 C)	150 PSIG	\$205.00
<b>AV-100-CPVC</b>	CPVC	1" NPT or BSP Thread	1" Thread	180 F (82 C)	150 PSIG	\$259.00
<b>AV-25-PVDF</b>	PVDF	1/4" NPT or BSP Thread	1/4" Thread	180 F (82 C)	150 PSIG	\$421.00
<b>AV-50-PVDF</b>	PVDF	1/2" NPT or BSP Thread	1/2" Thread	180 F (82 C)	150 PSIG	\$767.00
<b>AV-75-PVDF</b>	PVDF	3/4" NPT or BSP Thread	1/2" Thread	180 F (82 C)	150 PSIG	\$901.00
<b>AV-50-316S/S</b>	316 S/S	1/2" NPT or BSP Thread	1" Thread	500 F (260 C)	250 PSIG	\$348.00
<b>AV-75-316S/S</b>	316 S/S	3/4" NPT or BSP Thread	1" Thread	500 F (260 C)	250 PSIG	\$375.00
<b>AV-100-316S/S</b>	316 S/S	1" NPT or BSP Thread	1" Thread	500 F (260 C)	250 PSIG	\$413.00
<b>AV-150-316S/S</b>	316 S/S	1.5" NPT or BSP Thread	1.5" Thread	500 F (260 C)	250 PSIG	\$902.00
<b>AV-200-316S/S</b>	316 S/S	2" NPT or BSP Thread	2" Thread	500 F (260 C)	250 PSIG	\$1,048.00

Contact our office for more information on product availability and applications. Other materials available upon request.

## Typical Installation

The installation below is a typical installation example only. Consult your engineering department for the appropriate installation for your application or call the factory for advice.

**Example: System arrangement for solenoid driven (above 150 psig) or motor driven pumps with highly recommended flooded suction conditions.**

